

homeglowflex4^{by AGROMAX™}

instructions

Thank you for purchasing an
AgroMax™ Homeglow Flex 4 LED grow light!



BOX CONTENTS

A - Homeglow Flex 4 LED grow light
B - Light Stand **C - Power Adapter**



Connect fixture cable to the DC power adapter before plugging into the power source.



WARM WHITE SPECTRUM



COOL WHITE SPECTRUM



BLUE & RED SPECTRUM



Dimming Control

4 Brightness levels available. Press this button to cycle between the different levels.

Spectrum Control

3 Lighting modes available. Press this button to cycle between cool white, warm white, and blue+red spectrum.

Timer Control

3 Timer options available. Press this button to set an 8-hour, 12-hour, or 16-hour timer. The controller will illuminate to it's corresponding color.

Power ON/OFF

Press this button to turn the grow light on or off.



ATTACH LAMPS

The Homeglow Flex 4 LED grow light
attaches to the included adjustable
light stand.

